



**B6ST**

**6 Slice Commercial Toaster**



**User Manual**

The product is designed for use in a commercial environment by competent persons. The **B6ST** Toaster can be selected to toast 2, 4 or 6 slices of bread simultaneously

## Caution


- 1.) Do not plug in with wet hands in order to avoid the risk of electrocution
- 2.) Do not plug into already overloaded power sockets where several appliances are already plugged in
- 3.) Do not use if the power cord is damaged, or if the plug does not fit the socket safely
- 4.) Do not use the toaster near direct sources of heat or moisture
- 5.) Do not site in reach of small children, or allow children to operate the toaster themselves
- 6.) Always ensure the toaster is sited on a stable and even surface
- 7.) Do not cover the toaster openings or place anything on top of the toaster whilst still warm
- 8.) Allow the toaster to cool sufficiently before disconnecting to move or store
- 9.) Do not use metallic objects in the toaster like knives to dislodge debris
- 10.) Always ensure the toaster has sufficient surrounding space, the front and at least one side must be kept clear
- 11.) Do not use the toaster on tablecloths, carpets or thin vinyl and low heat resistant surfaces

## Putting Into Operation

Insert the plug into a suitable power source and insert the bread slices into the top of the toaster.

Select the number of slots to be toasted and turn the dynamic timer switch to set the toasting time (The power indicator will illuminate).

When the cooking time has expired, the bell will sound and the heaters will automatically shut off. To remove the toast, press down on the manual lever and remove the slices of toast




- 1 - Bread Entry Slot
- 2 - Options Switch
- 3 - Power Indicator
- 4 - Timer
- 5 - Body of Toaster
- 6 - Crumb Tray
- 7 - Manual Lifting Lever

# Electrical Parameters

Model	<b>B6ST</b>
Names	6slice toaster
Rated voltage (V)	220/50Hz
Rated power (KW)	2.5KW
Working hours 5min	0~5min
Work choose	Six
Dimensions	410*270*220

## Electrical Schematics



K1-timer switch    K2-choice Switches  
HL1-power indicator    R1~R5-electric panels

## Cleaning & Maintenance

- 1.) Before any cleaning or maintenance, you must ensure the toaster is disconnected from all power supplies and switched off.
- 2.) The daily maintenance should involve a thorough wipe down with a clean soft cloth, do not use abrasives like scouring pads and brillos, or any liquid chemicals or cleaners
- 3.) Remove the crumb tray from the bottom of the toaster and wipe down daily

## Troubleshooting

- 1.) Ensure there is power to the socket and that it is switched on
- 2.) Check the timer has been set and switched on
- 3.) Check the slice selector is on the highest number (6)
- 4.) Check the fuse in the plug of the appliance

## Repairs

- 1.) All repairs must be carried out only by a suitably qualified person
- 2.) The unit is supplied on a return to base warranty, please contact your supplier in the first instance to arrange repair



## Disposal



EU regulations require products to be disposed of by specialist companies who remove or recycle products, including electronic, metal and plastic components.

Consult your local waste collection authority regarding disposal of your appliance. Local authorities are not obliged to dispose of commercial equipment but may be able to offer advice on how to dispose of the equipment locally.

All packaging materials should be disposed of in an environmentally friendly way. The cardboard may be used as scrap paper. The protective foil and the foam cushions are CFC-free.

Do not allow children to play with the packaging and destroy plastic bags safely.

## Environmental protection



Discarded electric appliances are recyclable and should not be discarded in the domestic waste! Please actively support us in conserving resources and protecting the environment by returning this appliance to the collection centres (if available).

## Compliance

Parts have undergone strict product testing in order to comply with regulatory standards and specification set by international, independent, and federal authorities.

Products have been approved to carry the following symbol:

